



# Village of Bremen, Ohio

9090 Marietta Road  
P.O. Box 127  
Bremen, Ohio 43107

Phone: 740-569-4788      Fax: 740-569-7085

## Backflow Prevention and Cross-Connection Control

### Protecting our Public Water System

What is a cross-connection? Any physical connection created between a possible source of contamination and any drinking water system piping.

What is backflow? It is the flow through a cross-connection from a possible source of contamination back into the drinking water system. It occurs when a cross-connection is created and a pressure reversal, either as back-siphonage or backpressure, occurs in the water supply piping.

What are some common backflow hazards that threaten the homeowner and other consumers?

- Hose connections to chemical solution aspirators to feed lawn and shrub herbicides, pesticides or fertilizers.
- Lawn irrigation systems.
- Chemically treated heating systems.
- Hose connections to a water outlet or laundry tub.
- Swimming pools, hot tubs, spas.
- Private and/or non-potable water supplies located on the property.
- Water-operated sump drain devices.
- Feed lots/livestock holding areas or barnyards fed through pipes or hoses from your water supply plumbing.

What are examples of cross-connection and backflow scenarios?

- Soapy water or other cleaning compounds back-siphon into the water supply plumbing through a faucet or hose submerged in a bucket or laundry basin.
- Pool water back-siphons into the water supply plumbing through a hose submerged in a swimming pool.
- Fertilizers/pesticides back-siphon into the water supply plumbing through a garden hose attached to a fertilizer/pesticide sprayer.
- Chemicals/pesticides and animal feces drawn into the water supply plumbing from a lawn irrigation system with submerged nozzles.
- Bacteria/chemicals/additives in a boiler system back-siphon into the water supply plumbing.
- Unsafe water pumped from a private well applies backpressure and contaminates the public water supply through a connection between the private well discharge and the potable water supply plumbing.

### Why be concerned?

- All cross-connections pose a potential health risk.
- Backflow can be a health hazard for your family or other consumers if contaminated water enters your water supply plumbing system and is used for drinking, cooking or bathing. Chemical burns, fires, explosions, poisonings, illness and death have been caused by backflow through cross-connections.
- Backflow occurs more often than you think.
- You are legally responsible for protecting your water supply plumbing from backflow that may contaminate drinking water, either your own or someone else's. This includes complying with the plumbing code and not creating cross-connections.

What causes back-siphonage? Back-siphonage occurs when there is a loss of pressure in a piping system. This can occur if the water supply pressure is lost or falls to a level lower than the source of contamination. This condition, which is similar to drinking from a glass with a straw, allows liquids to be siphoned back into the distribution system.

What causes back pressure? Backpressure occurs when a higher opposing pressure is applied against the public water system's pressure. This condition allows undesirable gases or liquids from another system to enter the drinking water supply. Any pumping system (such as a well pump) or pressurized system (such as steam or hot water boilers) can exert backpressure when cross-connected with the public water system.

### What can I do?

- Be aware of and eliminate cross-connections.

- Maintain air gaps. Do not submerge hoses or place them where they could become submerged.
- Use hose bib vacuum breakers on fixtures (hose connections in the basement, laundry room and outside).
- Install approved, testable backflow preventers on lawn irrigation systems.
- Do not create a connection between an auxiliary water system (well, cistern, body of water) and the water supply plumbing.

## What must be done to protect the public water system?

The public water supplier must determine potential and actual hazards. If a hazard exists at a customer's public water supply service connection, the customer will be required to install and maintain an appropriate backflow preventer\* at the meter and/or at the source of the hazard.

\*Check with your water supplier to verify which backflow preventer is required before purchase or installation.

## Who is responsible?

In Ohio, the responsibility for preventing backflow is divided. In general, state and local plumbing inspectors have authority over plumbing systems within buildings while Ohio EPA and water suppliers regulate protection of the distribution system at each service connection.

Water customers have the ultimate responsibility for properly maintaining their plumbing systems. It is the homeowner's or other customer's responsibility to ensure that cross-connections are not created and that any required backflow preventers are tested yearly and are in operable condition.

If a potential or actual cross-connection contamination hazard is identified, the customer will be required to eliminate the hazard and/or install an appropriate backflow preventer at the service connection and/or at the hazard.

## Booster Pumps, what is the concern?

Booster pumps connected to plumbing systems or water mains can cause back-siphonage by reducing the water pressure in the main. Approved back-siphonage prevention methods are required.

- Booster pumps, not used for fire suppression, must be equipped with a low-pressure cut-off switch designed to shut-off the booster pump when the pressure in the service line on the suction side of the pump drops to ten pounds per square inch or less.
- It is the responsibility of the water consumer to maintain the low-pressure cut-off device in proper working order and have it tested

every twelve months. The test results are to be sent to the provider of water.

### Auxiliary Water Systems, what protection is required?

- The auxiliary water system must be completely separated from water supply plumbing served by a public water system; and
- An approved backflow preventer must be installed at the service connection (where the public water system connects to the customer's plumbing system).
- Or the auxiliary water system must be eliminated.